

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 2: Climb via heading 016°. Thence....
TAKEOFF RWY 20: Climb via heading 196°. Thence....
....Expect radar vectors to intercept filed/assigned transition or En Route
Fix/Navaid. Maintain 2500. Expect filed altitude/flight level 10 minutes after
departure.

ANDYS TRANSITION (HUG6.ANDYS): From over CLT VOR/DME via CLT R-196
to ANDYS INT. Thence as filed.
CHOPN TRANSITION (HUG6.CHOPN): From over CLT VOR/DME via CLT R-165
to CHOPN INT. Thence as filed.
DEBIE TRANSITION (HUG6.DEBIE): From over CLT VOR/DME via CLT R-255 to
DEBIE INT. Thence as filed.
GIPPR TRANSITION (HUG6.GIPPR): From over CLT VOR/DME via CLT R-093 to
GIPPR INT. Thence as filed.
PITTY TRANSITION (HUG6.PITTY): From over CLT VOR/DME via CLT R-286 to
PITTY INT. Thence as filed.
ROBAY TRANSITION (HUG6.ROBAY): From over CLT VOR/DME via CLT R-347
to ROBAY INT. Thence as filed.
SADIE TRANSITION (HUG6.SADIE): From over CLT VOR/DME via CLT R-347 to
SADIE INT. Thence as filed.

SE-2,14 APR 2005

SE-2,14 APR 2005